

ENGAGE[™] Polyolefin Elastomers Extrusion Guide

The ENGAGE[™] Polyolefin Elastomers (POEs) listed in Table 1 can be used in a variety of extrusion applications, including sheeting, tubing, and profiles. This guide will provide a processor with general equipment setup and troubleshooting guidelines to help successfully extrude and handle the product.

ENGAGE[™] POEs have a wide processing temperature window. The temperatures listed in Table 2 may be used as a reference point and can vary ±5°C. These temperatures can be further optimized, but normally will not require more than 10°C adjustment.

Polypropylene can be added to ENGAGE[™] Polyolefin Elastomers to provide a higher melting matrix that reduces setup time and increases part service temperature. Processing conditions noted in Table 2 may need to be modified to accommodate the higher melting point of the polypropylene.



Table 2: Extrusion Parameters (Starting Point)

Material	Melt °C	Die °C	Adapter °C	Zone 3 °C	Zone 2 °C	Zone 1 °C
ENGAGE [™] POE >0.890 density	205	205	205	205	195	180
ENGAGE [™] POE <0.890 density ⁽¹⁾	195	195	195	195	180	160

⁽¹⁾Use of a jacketed feed throat is recommended to avoid bridging with <0.890 density grades.

Table 3: Equipment and Processing

able 3: Equipment and Processing				
Equipment/Processing	Suggested Guidelines			
Extruder	L/D ratio 20:1 or higher			
Screw Type	General purpose polyolefin screw			
Compression Ratio	2.5:1-3.5:1			
Screen Pack	80/60/40 mesh			
Purge Compound	Shut down at 150°C with highly stabilized polyethylene			
Drying	Not required			
Recycling	Fully recyclable. Conventional granulators with sharp blades should be used.			
Regrind Usage	ENGAGE [™] POE is often used as a modifier for olefin recycle streams, but you should conduct regrind studies to determine specific limits for your application.			
Release Additive	An amide wax masterbatch is often beneficial for polymers < 0.890 density			
Tubing or Profile Extrusior	n			
Sizing	Either air or vacuum			
Water Bath	5-10°C			
Sheet Extrusion				
Chill Rolls	20-100°C – Adjust as needed for smooth surfaces			
Metal Release Additive	If needed for roll sticking			
Release Paper	Suggested for all grades if using polished rolls. Textured sheeting reduces need for release paper, especially for > 0.890 density grades.			

Table 1: ENGAGE[™] POEs for Extrusion Applications

Typical Physical Properties ⁽¹⁾	ENGAGE [™] 8540	ENGAGE [™] 8480	ENGAGE [™] 8440	ENGAGE [™] 8003	ENR ⁽²⁾ 7256	ENGAGE [™] HM 7387 ⁽³⁾	ENGAGE [™] HM 7487 ⁽³⁾
Density (g/cm³)	0.908	0.902	0.897	0.885	0.885	0.870	0.860
Melt Index (190°C, 2.16 kg)	1	1	1.6	1	2	<0.5	<0.5
Tubing and Profiles	•	•	•	•	•	•	•
Sheeting		•			•	•	•

⁽¹⁾Typical properties; not to be construed as specifications. Users should confirm results by their own tests.

²⁾ ENR designates a developmental grade. If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Dow to change specifications and/or discontinue production; and (4) although Dow may from time to time provide samples of such products, Dow is not obligated to supply or otherwise commercialize such products for any use or application whatsoever. (3) ENGAGE[®] HM 7387 POE and ENGAGE[®] HM 7487 POE are frequently used in combination with polypropylene.

Table 4: Additives(1)

Equipment/Processing	Benefit	Starting Point Levels of Active Ingredient
Amide Wax	Reduced surface tack	500 ppm (0.05%)
Fluoropolymer processing aid	Reduced melt fracture and die pressure	1000 ppm (0.1%)
Polydimethoxysiloxane (PDMS)	Scratch and mar	2000 ppm (0.2%)
Metal Release	Reduce adhesion to nip rolls	1000 ppm (0.1%)
Antioxidant or UV Stabilizer	Processing/end-use stability	As needed
Colorants	Product appearance	As needed

(1) Masterbatch of ENGAGE Polyolefin Elastomers preferred, but can also use Low Density Polyethylene (LDPE) or Linear Low Density Polyethylene (LLDPE) carriers.

Table 5: Troubleshooting

Issue	Possible Cause	Suggestion	
Melt fracture	Cold melt	Increase melt temperatures Increase die temperature	
	Melt not mixed	Use higher compression ratio screw Use screw with mixing section	
	Poor die design	Decrease land length	
	Heater not working	Check heaters and thermocouples	
	Polymer to metal friction or shear	Use Fluoropolymer processing aid	
Uneven cross-section	Surging	Decrease extrusion rate Use screw with long feed or metering section Use finer screen pack to increase back pressure	
High extruder pressure	Melt too cold	Increase melt temperatures Increase die temperature	
	Clogged screen packs	Replace screen pack Wider mesh screen pack reducing back pressure	

North America		Europe/Middle East	+ 800 3694 6367	dow.com
U.S. & Canada	1 800 441 4369		+ 31 115 672626	dowelastomers.com
	1 989 832 1426	Italy	+ 800 783 825	
Mexico	+ 1 800 441 4369	South Africa	+ 800 99 5078	
Latin America Argentina	+ 54 11 4319 0100	Asia Pacific	+ 800 7776 7776 + 603 7965 5392	
Brazil Colombia	+ 55 11 5188 9000 + 57 1 219 6000			
Mexico	+ 52 55 5201 4700			

The principles of Responsible Care® and Sustainable Development influence the production of printed literature for The Dow Chemical Company ("Dow"). As a contribution towards the protection of our environment. Dow's printed literature is produced in small quantities and on paper containing recovered/post-consumer fiber and using 100 percent soy-based ink whenever possible.

NOTICE: Any photographs of end-use applications in this document represent potential end-use applications but do not necessarily represent current commercial applications, nor do they represent an endorsement by Dow of the actual products. Further, these photographs are for illustration purposes only and do not reflect either an endorsement or sponsorship of any other manufacturer for a specific potential end-use product or application, or for Dow, or for specific products manufactured by Dow.

NOTICE: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the Customer is responsible for determining whether products and the information in this document are appropriate for the Customer's use and for ensuring that the Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Dow assumes no obligation or liability for the information in this document. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

NOTICE: If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Dow to change specifications and/or discontinue production; and (4) although Dow may from time to time provide samples of such products, Dow is not obligated to supply or otherwise commercialize such products for any use or application whatsoever.

NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS: Dow will not knowingly sell or sample any product or service ("Product") into any commercial or developmental application that is intended for: a. long-term or permanent contact with internal bodily fluids or tissues. "Long-term" is contact which exceeds 72 continuous hours; b. use in cardiac prosthetic devices regardless of the length of time involved ("cardiac prosthetic devices" include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic

- balloons and control systems, and ventricular bypass-assisted devices);
- c. use as a critical component in medical devices that support or sustain human life; or d. use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction.

Dow requests that customers considering use of Dow products in medical applications notify Dow so that appropriate assessments may be conducted.

Dow does not endorse or claim suitability of its products for specific medical applications. It is the responsibility of the medical device or pharmaceutical manufacturer to determine that the Dow product is safe, lawful, and technically suitable for the intended use. DOW MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CONCERNING THE SUITABILITY OF ANY DOW PRODUCT FOR USE IN MEDICAL APPLICATIONS.

This document is intended for global use. Published July, 2013. © 2013 The Dow Chemical Company

®™Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow [®]Responsible Care is a service mark of the American Chemistry Council. Dow is a partner in the American Chemistry Council Responsible Care initiative.